

•Mounting FD Bayonet Mount Lenses:

- 1) Move the aperture to the widest F/stop
- 2) Notice there are TWO index marks on the adapter
- 3) Align the lens red dot index mark with the first red dot on the adapter
- 4) Rotate the lens towards the second red dot on the adapter (this aligns the lens aperture pin correctly)
- 5) Once the lens stops, rotate the lens in the opposite direction, back towards the first red dot until the lens locks in place on the adapter
- 6) To remove the lens, press down on the lens release and rotate the lens back towards the second red dot.

•Mounting FD Breech Mount Lenses:

- 1) Move the aperture ring to any f/stop, but not the A or O setting
- 2) Make sure the largest aperture lug pin on the back of the lens is pushed clockwise (this is the only pin on the back of your lens which can be pushed back and forth)
- 3) Align the lens red dot index mark with the first red dot on the adapter
- 4) Rotate the lens towards the second red dot on the adapter
- 5) Rotate breech mount towards first red dot

•Mounting FL Breech Mount Lenses:

Align the mounting points on the lens and adapter, turn lens mounting ring to lock lens on adapter, make sure aperture switch is set to M so you have manual control of the aperture

